

# **R W McNAIR INC**

JANUARY 2012

1128 SECOND AVENUE NORTH      205-323-8003      BIRMINGHAM AL 35203 - 1530  
800-875-9876

**GUNITE-DRY PROCESS SHOTCRETE & REFRACTORY MACHINES**

## **GUN OPERATOR INSTRUCTION LABEL**

### **GUN OPERATOR INSTRUCTIONS**

**Pack Felt Down Tight to  
Seal Feed Bowl Rim Inside Hopper**

**Do Not Fill Hopper Above This Label**

**Tighten Wear Pad Setscrew Knobs  
to Seal Air Leakage Between  
Wear Pad and Feed Bowl**

**Do Not Over-Speed Air Motor**

### **QUESTIONS?**

**Phone Ray McNair @ 205-323-8003**

\*\*\*\*\*

**The purpose of this label is to put accountability on a gun operator,  
to help him to operate his Reed Gun efficiently.**

**The label addresses four important working points.**

**Attach the label to a clean surface INSIDE THE HOPPER,  
about four inches below the hopper rim or screen.**

**The label should be easily seen and readable  
by persons assigned to the gun operation.**

**The lowest two lines of the label give opportunity for an operator or owner to  
call me personally if they think that the machine isn't working right.**

**I can usually be reached by phone 24-7.**

**My intent is to help anyone who wants his Reed Gun to work at best performance.**

**If you don't want my name on the label, trim it off  
and use the rest of the label if it meets your expectations.**

**McNAIR Gun Operator Instruction Labels, Black & Yellow:  
Part Number 10001M, \$8.00 each, can be shipped with parts orders**